




1. Align lug locks on coupler with lug housing in top of keg; insert coupler.



2. Turn coupler ¼ turn clockwise; the coupler is now secured to keg.



3. Push down on the coupler and give another ¼ turn, to open beer and CO₂ ports in keg. The keg is now tapped.