

Easy Party Pump Cleaning Procedure :-

1. Remove the party coupler from the keg
2. Fill the cleaning bottle with cleaning chemical and warm water as per the manufacturer's instructions
3. Place the party coupler on the cleaning bottle
4. Use the party coupler to release out the mixture of cleaning chemical and warm water out of the cleaning bottle via squeezing faucet
5. Now add warm water in the cleaning bottle
6. Repeat step 4 to release out the warm water from the cleaning bottle via squeezing faucet

